

**What you will need:**  
A small screwdriver



### Step 1

Hold the 2 halves of the red Clamp on the frame with your thumb and forefinger as shown.



### Step 2

Position the O-Ring and hold with finger as shown.



### Step 3

Use the screw driver to grab the O-Ring and begin to stretch it across the face of the Clamp assembly.



### Step 4

Stretch the O-Ring until you can get the blade of the screwdriver over to the opposite edge of the clamp.



### Step 5

Work the O-Ring down the shaft of the screwdriver and it will pop into place and remove the screwdriver.

