

## ProTorq Instructions

### Using the ProTorq Drum Key

- 1) Pick a starting point on the dial 1-8 (*The numbers are relative and do not correspond to any specific pitch, go beyond 8 to the next revolution for more tension*)
  - 2) Move the plastic-tipped steel rod to the **Red Dot (A)**.
  - 3) Tighten the first drum lug until the rod clicks off the **Red Dot (B)**.
  - 4) Move the rod back to the **Red Dot** and tighten the opposite lug. When all lugs are tightened to the selected setting, they will be under equal tension and be in relative tune with each other.
- *Tip: Take note of the dial's numbers to remember your tension settings.*

